

<p><b>Linux driver for MCXUNI, MCXPCI, MCXCPCI and WAN-HDLC product ranges</b></p>
--

## Table of contents

<b>1</b>	<b>ABOUT MCXPCI, MCXCPCI &amp; WAN-HDLC CARDS .....</b>	<b>2</b>
1.1	Supported cards .....	2
1.2	Cards firmwares .....	2
<b>2</b>	<b>INSTALLING THE DRIVER FOR V2.6 KERNELS .....</b>	<b>3</b>
2.1	OS versions .....	3
2.2	Firmware selection .....	3
2.3	Recompiling the driver .....	3
2.4	Installation .....	4
2.5	Creating devices .....	4
2.6	Testing the driver and card .....	5
2.7	Unloading the driver .....	5
2.8	Miscellaneous changes .....	6
2.8.1	Driver version 1.2 .....	6
2.8.2	Driver version 1.4 .....	6
2.9	Limits .....	6
2.10	Known bugs .....	6
<b>3</b>	<b>INSTALLING THE DRIVER FOR V2.2 AND V2.4 KERNELS.....</b>	<b>7</b>
3.1	OS versions .....	7
3.2	Firmware selection .....	7
3.3	Recompiling the driver .....	7
3.4	Installation .....	7
3.5	Creating devices .....	7
3.6	Uninstalling the driver .....	8
3.7	Limits .....	8
3.8	Known bugs .....	8
<b>4</b>	<b>USING THE DRIVER .....</b>	<b>9</b>
4.1	System calls .....	9
4.1.1	Open function .....	9
4.1.2	Read fonction .....	9
4.1.3	Write function .....	10
4.1.4	Select fonction .....	10
4.1.5	Close fonction .....	10
4.1.6	Ioctl fonction .....	11
4.2	Using HDLC/ABM (a.k.a. LAP-B) and HDLC/NRM .....	12
4.3	C programming examples .....	14
4.4	Firmware upgrade tool .....	15

# 1 About MCXPCI, MCXCPCI & WAN-HDLC cards

## 1.1 Supported cards

The driver supports the following ACKSYS cards :

- MCXPCI/570 (-2 and -4), WAN-HDLC (/4 and /4C), MCXCPCI/570 (-2, -4, -2R, -4R) cards with the MCX-MULTIPROTOCOLE firmware
- MCXPCI/BP and MCXPCI/S with either the standard firmware or the MCX-MULTIPROTOCOLE firmware

## 1.2 Cards firmwares

Firmware	Standard (basic)	MCX-MULTIPROTOCOLE
Runmode Serial communications format	1 asynchronous	2 asynchronous, isochronous, HDLC, character-oriented synchronous, asynchronous synchronized, custom option
MCXPCI/BP	standard feature	option
MCXPCI/S	standard feature	option
MCXPCI/570	reduced functionality(*)	standard feature
MCXCPCI/570		
WAN-HDLC	reduced functionality(*)	standard feature
WAN-HDLC/4C		

(\*) global card commands (RELRP) are available but not channel commands (VINIT...)

## 2 Installing the driver for v2.6 kernels

### 2.1 OS versions

The driver was tested with the following kernels:

- Debian 3.1 (sarge) i386, preemptive kernel v2.6.8 with SMP.
- Debian 4 (etch) i686, preemptive kernel v2.6.18 with SMP.
- SuSE 10.0 x86\_64, preemptive kernel 2.6.13 with SMP.
- RedHat 4.2.1.3 (nash) i386, kernel v2.6.19-11.EL (smp/preemption unknown).
- RedHat Fedora Core 9 (sulphur) i686, kernel 2.6.25 with SMP.

32-bits executables compiled for the i386 architecture are supported when run in the x86\_64 architecture.

### 2.2 Firmware selection

The RUNMODE constant in the mcx.h file controls the default choice for the firmware to be activated at card startup. To change the default you could change the RUNMODE value and recompile the driver.

Preferably, you may select the firmware at module load time using the “runmode=...” option.

Refer to the “Cards firmwares” section to select the correct value for the run mode.

### 2.3 Recompiling the driver

**WARNING:** a Linux driver must be compiled for the exact kernel configuration on which it will be used. Otherwise module load warnings or errors, and even system crashes can happen.

To compile the driver you do not need root privilege; but you need it to install it and run it.

You must have the kernel source tree installed and configured. Usually you should use the config file located in the /boot directory of the target computer. Also, you must have the GCC compiler installed (the version which is recommended by your Linux distribution provider).

- Use the command prompt.
- Extract the driver source files to a directory of your choice.
- go to this directory.
- type “**make**” to compile the driver.

Unusual kernel source tree location: you can customize the “**Makefile**” file used by “**make**” and “**make install**” if your distribution uses an unusual kernel source tree. Check the KDIR directory which indicates the kernel sources location, and use the O=... argument to indicate where the kernel configuration and compilation output reside, if this is different from KDIR.

## 2.4 Installation

Make sure that the board is correctly installed in your computer, and that the serial connectors box, if any, is plugged in the card.

- type “**insmod mcxpci.ko**” to check for correct loading of the module.

If a MCXPCI card is installed in the computer, its LEDs should stop blinking wildly and LED 0 should blink at a one-second rate.

The driver supports options to select the firmware to run (basic or multiprotocol) and the initial electrical interface for all ports.

Example:

```
insmod mcxpci.ko runmode=2 ifmode=8
```

**Runmode** is 1 or 2: see section 1.2.

**Ifmode** is working only in runmode 2 and the available values are described in the Multiprotocol manual, in the RSMDE command.

The default values are runmode=2 (multiprotocol firmware) and ifmode=0 (RS232).

If the devices connected to the serial ports of the card are not all RS232, **you should use ifmode=8 (tri-state mode)**.

- You can check the kernel log to find information about the cards detected by the driver (usually in “/var/log/messages”, the name may depend on the Linux distribution).
- Type “**rmmod mcxpci**” to check for correct unloading of the module.
- type “**make install**” to copy the module to your /lib/module directory and run depmod.

After that you should be able to run “**modprobe mcxpci**” from any directory to load the module. If this fails, the module was not copied to the correct subdirectory in /lib/modules. Run “**uname -r**” to know the name of the correct subdirectory, move the module there and rerun depmod.

## 2.5 Creating devices

The driver is designed to work with the “**sysfs**” kernel option and the “**udev**” package. Together they will handle the creation of the cards device nodes in /dev. Use of the “**mknod**” command is deprecated. Beware that the default rules for udev will create nodes that are accessible only with root privilege.

In the driver source directory there is a “**mcxpci.rules**” file that you can drop to /etc/udev/rules.d”. **udev** will then create the required devices for you each time the driver starts. It has been tested with Debian sarge and Debian etch.

The device class used in “**sysfs**” for the driver is named “mcx”. Character devices are used. The major device number, if needed, can be found in /sys/class/mcx/\*/dev or in /proc/devices.

For each card having N serial channels, two series of N+1 device nodes are created. One serie allows to identify the slot in which the card is inserted, so as

to be independent of later insertion of more cards. The other serie is compatible with previous versions of the driver, and names the channels sequentially through any number of cards.

The first, slot-dependant, serie is named “/dev/mcxBBSS-CC” where BB is a PCI bus identifier, SS is a PCI slot identifier, CC is a channel identifier. CC is 01 to NN to represent a card with NN serial channels. CC has the special value 00 to allow access to the card itself without specifying a channel. CC is also the minor device number.

The second, slot-order-dependant, serie is named “/dev/mcxXX” where XX is a number in the range 00 to (number of available channels + number of available cards). 00 allows access to the first card found, 01..NN to the NN serial channels of the first card, NN+1 to the second card, NN+2..MM+NN+2 to the MM serial channels of the second card, and so on.

## 2.6 Testing the driver and card

You can make a simple transmit/receive test in the following manner.

- Load the driver as explained above. We will suppose that the port devices are named /dev/mcx01, /dev/mcx02 and so on.
- Go to the “utils/testloop” directory and insure that testloop is compiled (otherwise compile it with “make testloop”).
- Go to the “examples” directory and compile initall (“make initall”).
- Remove any cable connected to your equipments. Instead plug in a loopback connector consisting in only a TxD/RxD strap (pin 2 to pin 3).
- Initialize the port:
 

```
./initall 1 0 e RS232 100
```
- Run a loopback test:
 

```
../utils/testloop/testloop mcx01 0 100
```

This test runs forever, sending numbered frames to the port, receiving its own frames, checking for errors and displaying data throughput every 10 seconds.

## 2.7 Unloading the driver

“**rmmod mcxpci**” uninstalls the driver and reboots the boards. If you reload the module immediately, there will be a long delay while the card is running its self-test.

## 2.8 *Miscellaneous changes*

### 2.8.1 Driver version 1.2

- Ioctl control codes: MCX\_IOC\_CMD\_AUTO, MCX\_IOC\_GETCARD and MCX\_IOC\_GETCONF ioctl.
- User-mode write buffers greater than channel buffers are now handled.
- Much better signal handling.
- The default behaviour of read() is now to wait for incoming data. Interrupt conditions IT2 and IT7 are now set by default. This allows the channels to be used from standard Linux utilities like “cat”. A driver compile-time option allows to set back the old behaviour.
- No driver-imposed limits on the number of cards.

### 2.8.2 Driver version 1.4

- Support for the HDLC link layer protocols (LAP/B, ABM, NRM).
- Handling of control signal state changes as events detected by the poll and select system calls.
- MCX\_IOC\_GETEVENTS and MCX\_IOC\_SETEVENTS ioctl.

### 2.8.3 Driver version 1.4.6

- Compilation warnings removed.
- New INSMOD option for settable initial electrical common interface.
- A new tool allows upgrading the card firmware under Linux.

## 2.9 *Limits*

The driver is supported only on i386 and x86\_64 architectures. Other architectures have not been tested, they may work if they support access to a PCI memory region through a kernel virtual pointer.

## 2.10 *Known bugs*

Command timeout is not correctly handled on kernels prior to 2.6.13. However commands should never timeout on cards with correctly set serial connectors.

## 3 Installing the driver for v2.2 and v2.4 kernels

### 3.1 OS versions

The driver was tested in the following conditions:

- Mandrake 7.2 kernel 2.2.17
- Mandrake 8.0 kernel 2.4.3-20
- Redhat 7.2 kernel 2.4.7-10

### 3.2 Firmware selection

The RUNMODE constant in the mcx.h file controls the default choice for the firmware to be activated at card startup. To change the default you must change the RUNMODE value and recompile the driver.

Refer to the “Cards firmwares” section to select the correct value for the run mode.

### 3.3 Recompiling the driver

Type : **make install** within a directory which contains the Makefile, mcxpcidr.c, cmd.h, mcx.h, mcxpci.h, sysdep.h, typegc.h files

### 3.4 Installation

Make sure that the board is well installed in your computer.

From the correct directory, type : **insmod mcxpcidr**

The driver itself detects the MCXPCI boards, installs them and writes boards information in the file /var/log/messages

### 3.5 Creating devices

Each channel or line of the board is represented by a character type device. It is possible to create a device with a major/minor number by using the “mknod” command.

The major number is given by the system and is written in the /var/log/messages file upon driven installation completion, for example :

« FIN d’initialisation MCXPCI => OK (mcx\_major= 254) »

Upon driver installation completion, it is necessary to keep the major number and then create the devices.

The driver takes the minor number of the device as line number, it is recommended to name a device depending to its minor number.

For example, the « **mknod /dev/mcx01 c 254 1** » command creates the /dev/mcx01 device is character mode with a major equal to 254 and a minor equal to 1, which is the first line of the board.

Thus, the « **mknod /dev/mcx04 c 254 4** » command creates the /dev/mcx04 device which is the fourth line of the board.

Example for a PC with MCXPCI/570-4 boards installed :

- The minor number of a line on the first board varies from 1 to 4.
- The minor number of a line on the second board varies from 5 to 8.

Example for a PC with MCXPCI/BP-32 boards installed :

- The minor number of a line on the first board varies from 1 to 32.
- The minor number of a line on the second board varies from 33 to 64.

### 3.6 *Uninstalling the driver*

The « **rmmod mcxpcidr** » uninstalls the driver and reboots the boards. It is necessary to wait for the end of the boards reset cycle (LEDS goes from left to right quickly again and again) displays before reinstalling the driver with the « **insmod mcxpcidr** ».

### 3.7 *Limits*

- All the firmware commands (except rinit) indefinitely wait for the end of command interrupt, it means that there's no timeout mechanism implemented.
- A board dedicated command (not a command specifying a channel) should be always sent to a real channel (it concerns GOADR, MBOOT , NOPER, RELRP, RMEMO, RSTAT...).
- The maximum number of channel supported with a single PC is 127.
- All the installed boards within a same PC must use the same firmware (standard or MCX-MULTIPROCOLE), mixing firmware is not supported.

### 3.8 *Known bugs*

Some people encountered driver installation failure, « **insmod mcxpcidr** » returns an error.

This issue occurs only after trying to uninstall the driver using the « **rmmod mcxpcidr** » command.

## 4 Using the driver

### 4.1 System calls

#### 4.1.1 Open function

As per Linux documentation. Open can fail if called with a device node name associated with a minor device number out of range. When issued to a non-yet-opened port, `open()` runs the RXENB (if opened read/write) and MINTR on the channel.

#### 4.1.2 Read function

**read**: reads received frames. **read()** can be blocking or not depending on whether the file was opened with the `O_NONBLOCK` flag or not.

Use the “select” system call to avoid waiting indefinitely with a blocking read.

In synchronous modes (bisync, HDLC...), **read()** reads a frame. In asynchronous mode, **read()** reads *n* characters (see the RDBUF command of the board built-in firmware).

**read()** returns a 32 bits value:

- All zeroes if the link is down in HDLC stateful protocols
- 8 bits (bits 24-31) error code composed of either:
  - for asynchronous communications, 8 bits indicating the kind of error in the received data. See the description for IT5 interrupt in asynchronous mode, in the firmware user manual;
  - for synchronous communications, 4 bits (bits 28-31) indicating the a combination of flaws incurred by the received frame.
    - 0x00 = frame is good
    - 0x10 = frame closed by an ABORT instead of a flag
    - 0x20 = character buffer overflow in the USART
    - 0x40 = CRC error
    - 0x80 = frame buffer overflow in the card memory.
 See the description for RDBUF in synchronous mode, in the firmware user manual code;
  - zero, if the returned data incurred no error.

If an error happened, **read()** returns `-1` and sets `errno` to either:

- `EFAULT` if the given buffer is invalid (incorrectly allocated);
- `EAGAIN` if non-blocking I/O is required and reading would block;
- `EIO` in case of a card command error;
- `EINTR` if a signal was received while processing the system call.

Example:

```
int ReadLen, Error;
char RxBuf[1024]; // buffer where the driver will write received frame
ReadLen = read(fd, RxBuf, sizeof(RxBuf));
If (ReadLen < 0) {
    perror("read");
} else {
    // error code, 0= no error
    Error = (unsigned)ReadLen >>24;
    Number of read bytes = ReadLen &0x0FFFFFFF;
}
```

### 4.1.3 Write function

**write** : sends a frame and returns the length successfully written to the transmit buffer of the card, or it returns `-1` if an error happened, in which case `errno` is set to:

- `EFAULT` if the given buffer is invalid (incorrectly allocated);
- `EBUSY` if transmit buffer is full (only in kernels 2.4)
- `EAGAIN` if non-blocking I/O is required and writing would block
- `EIO` in case of card command error

**write()** finishes when the board sends the End Of Command Interrupt and not when the frame is completely transmitted.

The `SyncWrite` flag of the `MCX_IOC_SETCONF` `ioctl` blocks the **write()** system call until the frame is completely transmitted on the line.

Example:

```
char TxBuf[1024];           // transmit buffer
int txlen, txsent;         // number of characters to send
txlen = whatever depending on the app;
txsent = write(fd, TxBuf, txlen);
If (txsent < 0) {
    perror("write");
} else {
    Number of bytes successfully written = txsent;
}
```

### 4.1.4 Select fonction

**select** : waits (with time-out) until a “read” or “write” operation is possible without blocking.

“read” select waits for the `IT1` interrupt event which indicates that a synchronous frame or some asynchronous characters has been received allowing to start a nonblocking read. Also, a HDLC link down state triggers this event, and the following `read()` calls will return `0` (end of file indication).

“write” select waits for the `IT7` interrupt event which indicates that the transmit buffer is empty, hence the previous write is complete (all characters sent).

“exception” select waits for the `IT6` interrupt event which indicates either that a control signal changed, or that the link state changed when using the HDLC stateful protocols. Use the `MCX_IOC_SETEVENTS` `ioctl` control code to individually enable the events. Once triggered, the events stay around (they retrigger forever) until `ioctl` is called with the `MCX_IOC_GETEVENTS` control code.

### 4.1.5 Close fonction

**close** : closes the channel and runs the `RXENB`, `CLRRX`, `MINTR` commands of the firmware.

`RXENB` disables reception, `CLRRX` clears receive buffers, `MINTR` disables any interrupt sources from the target channel.

#### 4.1.6 ioctl fonction

**MCX\_IOC\_SETCONF** configures a channel by running the PROTO, RSMDE, STSIG, VINIT, MINTR, ALLOC, RXENB commands according to the parameters of the “Mcx\_Line\_CONFIGURE” structure.

When the board runs the basic firmware (instead of the MULTIPROTOCOL firmware), the PROTO command is ignored.

In synchronous mode, the “ALLOC” command is called only if TxBufSize and/or RxBufSize are not equal to zero in the Mcx\_Line\_CONFIGURE structure.

To set a protocol not directly supported by MCX\_IOC\_SETCONF, use MCX\_IOC\_CMD ioctl and execute the following commands : PROTO, RSMDE, MINTR, VINIT, RXENB (and PRCTL for protocols which requires connect/disconnect procedures).

A group of macros are available to set the parameters for the HDLC protocols in the Mcx\_Line\_CONFIGURE structure. See “mcx.h”.

#### **MCX\_IOC\_CMD**

writes to the board any command supported by the card firmware and waits for the end of command interrupt. All commands are fully documented in the relevant firmware user’s manual.

Command parameters must be filled in the mcc\_cmd structure.

If the send\_data and send\_data\_leng parameters of the mcc\_cmd structure are not null, application data pointed to by send\_data is written to the card “data” area..

If return\_data and ret\_data\_leng are not null, the card “data” area is written back to the application return\_data buffer.

In kernels 2.2 and 2.4, commands like RELRP, RSTAT... which are not channel- specific, are always sent to channel 1.

#### **New ioctl codes supported in 2.6 kernels:**

**MCX\_IOC\_GETCONF** reads back the structure set by a previous MCX\_IOC\_SETCONF.

**MCX\_IOC\_CMD\_AUTO** writes to the board any command supported by the standard or the MCX-MULTIPROTOCOLE firmwares and changes bits 0-6 of parameter 1 to the channel number which matches the current file descriptor. The functionality is the same as **MCX\_IOC\_CMD** but allows to write channel-independent code.

**MCX\_IOC\_GETCARD** obtains general information about the card and channel associated to the current file descriptor. Before using this ioctl you must set up a Mcx\_Card structure and set its mc\_size element to sizeof(Mcx\_Card).

**MCX\_IOC\_SETEVENTS** sets a mask of card events that will trigger the exception event in the **poll()/select()** system calls. Only the selected events will wake up these system calls. The initial mask is empty (nothing triggers select exceptions). See the “test\_abm.c” example code.

**MCX\_IOC\_GETEVENTS** reads a mask of the events which happened since last use of this ioctl code. Also, clears the pending events, so that a future call to **select()** will wait for a new event.


## 4.2 Using HDLC/ABM (a.k.a. LAP-B) and HDLC/NRM

You are urged to refer to the sample programs “`test_abm.c`” and “`test_nrm.c`”. To use this mode, you must first set up the port with an ioctl using the `MCX_IOC_SETCONF` code.

You should set `MCX_IOC_SETEVENTS` in order to detect link state changes in a `select()` without a busy-wait.

You can check the current link state or change it with a `MCX_IOC_CMD_AUTO` ioctl using the `PRCTL` command.

### Driver states



There are four states in the driver: `MCX_LINK_OFF`, `MCX_LINK_ON`, `MCX_LINK_GO_UP`, `MCX_LINK_GO_DN`. The state changes can result from a user program action (calling `PRCTL`) or from a card or remote action (link error detection, close by remote).

New state	Triggered by
MCX_LINK_OFF (down, disconnected)	<ul style="list-style-type: none"> <li>• <b>MCX_IOC_SETCONF</b> switching to a stateful protocol</li> <li>• <b>MCX_IOC_CMD_AUTO</b> with PRCTL HDLCLNKDN command (if the disconnection occurs after the command has finished)</li> <li>• State interrupt, failure of an attempted connection by PRCTL HDLCLNKUP</li> <li>• State interrupt, disconnection following a fatal transmission error</li> <li>• State interrupt, successful disconnection request by PRCTL HDLCLNKDN</li> </ul>
MCX_LINK_GO_UP (connection in progress)	<ul style="list-style-type: none"> <li>• <b>MCX_IOC_CMD_AUTO</b> with PRCTL HDLCLNKUP command</li> <li>• State interrupt, temporary disruption following a recoverable error</li> </ul>
MCX_LINK_ON (up, connected)	<ul style="list-style-type: none"> <li>• <b>MCX_IOC_CMD_AUTO</b> with PRCTL HDLCLNKUP command (if the connection occurs before the end of the command)</li> <li>• State interrupt, reception of a request or acknowledgement of a connection</li> </ul>
MCX_LINK_GO_DN (break in progress)	<ul style="list-style-type: none"> <li>• <b>MCX_IOC_CMD_AUTO</b> with PRCTL HDLCLNKDN command</li> </ul>

### Effect of state changes

No action is taken when the state change is caused by the application. The table below summarizes the action taken when a state change is interrupted.

New state	Action
MCX_LINK_OFF	<p>MCX_IT6_EVLINK signaled to select() if specified by an earlier <b>MCX_IOC_SETEVENTS</b> ioctl.</p> <p>Any further <b>read()</b> will return 0 characters</p> <p>Any <b>write()</b> will return early with an incomplete byte count.</p>
MCX_LINK_ON	<p>MCX_IT6_EVLINK signalled if specified by an earlier <b>MCX_IOC_SETEVENTS</b> ioctl.</p>

### 4.3 C programming examples and tools

All programs described below are available from the distribution media. To compile an example program “**XXX.c**” type “**make XXX**” (without the .c extension).

---

<b>initall</b>	Initialize one or more channels in asynchronous, bisync or HDLC modes.
----------------	--

---

<b>mcxdbg</b>	For those writing their own firmware, this sets up a debugging port. Usage: <code>mcxdbg /dev/config-port debug-channel</code>
---------------	---

---

<b>rtx</b>	Send frame and loop on receive.
------------	---------------------------------

---

<b>relrp</b>	Return board information, see the RELRP command in the firmware user’s manual for more information.  Usage: <code>rsmde /dev/mcxXX</code>  <i>/dev/mcxXX</i> designates any channel of the desired board.
--------------	--

---

<b>rstat</b>	Return information about communication channels; see the RSTAT command in the firmware user’s manual for more information.
--------------	--

---

<b>rsmde</b>	Set the electrical interface of a selected channel to whatever.  Usage: <code>rsmde /dev/mcxXX number</code>  where <i>number</i> is 0 for RS232, 1 for RS422, and so on. See the RSMDE command in the firmware user’s manual for more information.
--------------	--

---

<b>testloop</b>	(Kernel 2.6 only): multithreading send frame and loop on receive, displays channel receive throughput, similar to the Windows version of <b>testloop</b> .
-----------------	--

---

<b>test_abm</b> <b>test_nrm</b>	(Kernel 2.6 only): a small app that opens a MCXPCI port, sets it to HDLC/ABM (resp. NRM) and RS422, requests the establishment of the link, then waits for input from the standard input or the port. Data from the port is displayed, data from the standard input is sent to the port.  Usage: <code>test_abm [options] /dev/mcxXX RemoteAddress</code> <code>test_nrm [options] /dev/mcxXX LocalAddress</code>  Where <i>RemoteAddress</i> is either 1 or 3. Using address 3 will make <code>test_abm</code> issue a passive connection call (establish a server), while using address 1 will issue an active connection call (establish a client). In NRM mode <i>LocalAddress</i> can be anything; use the proposed commands to listen, call the remote or disconnect.  You may use it by connecting together two MCXPCI ports with a crossed (data and clocks) RS422 cable, and running it twice, one in passive link mode, one in active link mode. In “ <code>test_abm</code> ” The link mode is deduced from the address value (1 is active, 3 is passive).  Options can be -2 (set to RS232), -4 (set to RS422), -b baudcode (the codes are described in the VINIT command of the Multiprotocol documentation).
------------------------------------	---

---

#### 4.4 Firmware upgrade tool

The program named 'mcxflash' in the 'tools' subdirectory can be used to change the firmware installed in the card Flash EPROM memory.

Usage:

```
MCXFLASH "Device" "File.FLH"
```

"Device"	This is the name of the generic device associated with the card, namely /dev/MCXBBSS-00. BBSS depends on the PCI bus and slot where the card was installed.
"File.FLH"	This is the name of the FLH file containing the firmware. Its name must end in ".FLH" and its size must be 512 kbytes.

#### Warnings :

1) The MCXFLASH program can only work when the card is running the so-named "Basic Firmware, but not when it is running the "Multiprotocol Firmware". To achieve this, the driver must be installed in RUN01 mode, using the "runmode=1" option in insmod/modprobe.

Example:

```
Insmod mcxpci.ko runmode=1
```

2) MCXFLASH MUST NOT be interrupted in any way (even due to a power supply breakdown) since the card might not be able to restart.

3) Flashing a wrong firmware may render the card unusable. Always check the FLH file before trying to load it with MCXFLASH.

#### Four-steps guide to MCXFLASH

1. Unload the driver if needed:

```
root# rmmod mcxpci
```

2. Restart the driver in run01 mode:

```
root# modprobe mcxpci runmode=1
```

3. Run the MCXFLASH program:

```
root# mcxflash /dev/mcxbbss-00 file.flh
```

4. Shutdown and restart the computer:

```
root# reboot
```

The new firmware is now ready to use.